

Homebuilt/Experimental Tire Application Fitment Guide

<u>Aircraft Make</u>	<u>Model</u>	<u>Main</u>	<u>Auxiliary</u>
Van's RV	RV3-9	5.00-5 6PR	11/400-5 or T/W
	RV10	15/6.00-6 6PR	5.00-5 6PR
	RV12	5.00-6 6PR	5.00-5 4PR
Thorp	T18	5.00-5 6PR	T/W
Pitts	S1 S2	5.00-5 6PR	T/W
Busby	M/Mustang	5.00-5 6PR	T/W
Rutan	EZ series	11/4.00-5 8PR	280/250-4 6PR
Rans	S7S	6.00-6 4PR	T/W
Glasair	Glastar/2+2	5.00-5 6PR	11/400-5 8PR
		6.00-6 6PR	T/W
		8.00-6 6PR	T/W
	TD/FT (Airtrac)	5.00-5 6PR	11/400-5 or T/W
	I/II/IIRG/III(GY FSII)	5.00-5 6PR	11/400-5 8PR
Lancair	235/320/360	11/400-5	11/400-5
	Legacy	5.00-5 6PR	11/400-5 8PR
	IV	15/600-6	500-5

Desser Tire & Rubber Co. Inc.